



Enviro Chemicals

"Products that don't cost the Earth"

5L & 15L
PACK SIZES

DESCALER

ULTIMATE PROTECTION FOR YOUR EQUIPMENT

REMOVES CALCIUM • LIME SCALE • RUST STAINS

Powerful descaling formula that removes calcium build-up, lime scale and rust stains from dishwashers and metal surfaces. Helps maintain equipment performance and extend the life of your machines.



REMOVES
CALCIUM BUILD-UP



REMOVES
LIME SCALE



REMOVES
RUST STAINS



PROTECTS
EQUIPMENT



RESTORES
EFFICIENCY



SUITABLE FOR
DISHWASHERS



SUITABLE FOR
STAINLESS STEEL



HEAVY DUTY
DESCALING ACTION

POWERFUL SOLUTION FOR SPARKLING CLEAN RESULTS!



LIME SCALE REMOVAL



STAINLESS STEEL PROTECTION



RUST STAIN REMOVAL



OPTIMAL PERFORMANCE

PRODUCT DESCRIPTION

DESCALER is a powerful descaling solution that removes calcium build-up, lime scale and rust stains from commercial dishwashers and metal surfaces.

Regular use helps restore efficiency, protects equipment and extends the life of your machines.

Ideal for commercial kitchens, dishwashers, glass washers, heating elements and stainless steel equipment.

Safe to use when instructions are followed. Designed for professional cleaning results.

DIRECTIONS FOR USE

- 1 Turn Rinse/Detergent Dispenser OFF.
- 2 Turn Dish Machine off and empty.
- 3 Refill the machine and run one full cycle. Repeat step 2.
- 4 Refill the machine and add Descaler (20 mL per litre of water in wash tank). Ensure you have your gloves and safety glasses on.
- 5 Run the machine for one full cycle and inspect the interior. If scaling is still present, scrub areas of concern with a hard bristle brush. Close the machine and run a wash cycle.
- 6 Inspect the machine again and repeat step 5 until you are happy with the appearance of the machine.
- 7 Turn machine off and empty.
- 8 Refill and run the machine for one full cycle.
- 9 Turn the machine off and empty.
- 10 Turn the Rinse/Detergent Dispenser ON.
- 11 Refill the dish machine and run.

DO NOT skip steps 3 & 8 as the water pumps hold water, even if the machine is empty. You cannot mix even a SMALL amount of Descaler and dish detergent: this will cause a toxic gas!

WHERE TO USE

- ✓ Commercial Dishwashers
- ✓ Glass Washers
- ✓ Commercial Kitchens
- ✓ Heating Elements
- ✓ Stainless Steel Equipment
- ✓ Food Processing Equipment
- ✓ Wash Tanks
- ✓ Mineral Stained Surfaces
- ✓ Metal Surfaces

PROTECT
RESTORE
PERFORM

KEY BENEFITS

- ✓ Removes calcium build-up
- ✓ Removes lime scale
- ✓ Removes rust stains
- ✓ Protects equipment
- ✓ Restores efficiency
- ✓ Suitable for dishwashers
- ✓ Suitable for stainless steel
- ✓ Heavy duty descaling action
- ✓ Easy to use
- ✓ Saves time & money
- ✓ Environmentally responsible when used as directed

TECHNICAL DATA

Appearance	Colourless Liquid
Odour	Odourless
pH	Less than 1.0
Specific Gravity	1.41 ± 0.02
Flash Point	Non Combustible
Water Solubility	Miscible with Water

SAFETY INFORMATION

SIGNAL WORD: **DANGER**

- ✓ Corrosive to metals.
- ✓ Harmful if swallowed.
- ✓ Causes severe skin burns and eye damage.
- ✓ May cause respiratory irritation.
- ✓ Harmful to aquatic life.
- ✓ Keep out of reach of children.
- ✓ Read safety directions before opening.
- ✓ Wear protective gloves, clothing and eye/face protection.



FOOD SAFETY ASSURANCE

This product is AQIS approved and suitable for use in kitchens and food handling areas. When used as directed.

